

2018 M-SERIES TROLLEY SEAT



Tools Required
Allen key (supplied)



Assembling and Fitting the Seat

- 1** | The main section of the seat will arrive in two parts. Attach the padded seat top to the twin tubed section so that the seat overhang aligns with the feet (fig. 1)
- 2** | Insert the nuts and bolts in position and secure using the Allen key provided (fig. 1 inset)
- 3** | Insert the seat bar into the housing on the underside of the trolley (fig. 2)
- 4** | There should be roughly the same amount of tube on both sides of the housing (fig. 2 inset)
- 5** | Secure the seat bar within the housing by turning the underside lever anti-clockwise (fig. 3)
- 6** | Slot the legs of the seat onto the end of the seat bar (fig. 4)
- 7** | The correctly attached seat should look like this (fig. 5)

